



Section #12

# Installation Procedure

Phase II Coaxial EVR Balance Fuel Hoses

<b>Part:</b>	VST- VDV -EVR VST- VSTA -EVR
--------------	---------------------------------

***Vapor Systems Technologies, Inc.***

*650 Pleasant Valley Drive*

*Springboro, Ohio 45066*

*PH: 937-704-9333*

*FX: 937-704-9443*

*[www.vsthose.com](http://www.vsthose.com)*

# 1 General Information

---

If hanging hardware components are involved in a drive-off or incur other customer abuse, each individual component must be functionally tested prior to customer dispensing activities.

## 2 Installation Preparation

---

This procedure must be followed to insure leak-proof installation and operation of these nozzles.

1. Turn off and tag the power to the dispenser. Dispenser must be de-energized prior to service to avoid personal injury.
2. Barricade work area to block vehicle access to the dispenser.
3. Close the dispenser shear valve prior to removing hanging hardware (hoses, safety breakaways, and nozzles).
4. Drain liquid product from the hanging hardware set into an approved container prior to replacing any hanging hardware components.
5. Remove hanging hardware from the dispenser prior to making replacement component assembly connections. (VST recommends connection the whip hose to the dispenser as the last connection during hanging hardware re-assembly.)

## 3 Installation and Function Tests

---

1. Initial inspection:
  - a. Carefully unpack hose from shipping carton.
  - b. Inspect All O-Rings on each end of the hose to determine that they are present and undamaged.
  - c. Inspect hose exterior for any damage.
  - d. Inspect coupling threads for any damage.
2. Lightly lubricate **ALL** O-Rings on mating connections with petroleum jelly or other suitable lubricant. **DO NOT USE** pipe dope or thread sealant.
3. Insert the hose coupling into the mating connection and hand-tighten.

**NOTE:**

Be sure to not the flow direction arrows on whip and primary hoses, where applicable, are indicated on hose coupling cuffs.

4. Tighten all the hose-joint connections to 50 foot-pounds of torque. **DO NOT OVER TIGHTEN.** Use a torque wrench with an open-end attachment to fit the hose couplings and an open-end wrench to properly tighten coupling connections.

**DO NOT USE** channel-locks or pliers to tighten hose joints. Proper ft-lb. torque may not be achieved with these tools.

5. Purge air from the system by pumping one-tenth (1/10) to two-tenths (2/10) of a gallon of fuel into an approved container. Inspect each hose-joint connection for liquid leaks and make proper adjustments if necessary.
6. Check the nozzle shut-off action by dispensing fuel into an approved container at least three times to assure proper automatic operation of the nozzle interlock rod.

To test, operate the nozzle and submerge the spout tip in fuel until the fuel level covers the vent hole. The main valve of the nozzle automatically shuts off when liquid covers the vent hole at the end of the spout. The nozzle is not designed to operate on gravity flow. The hold-open latch will disengage automatically when liquid covers the vent hole in the spout.

Verify that the fuel flow stops when the nozzle collection sleeve is decompressed (e.g. interlock rod is disengaged). To test, dispense fuel into an approved container. Slowly remove the nozzle from the container while dispensing fuel. Fuel flow should stop when the nozzle collection sleeve is fully decompressed.

7. Measure the resistance between the dispenser outlet casting and the tip of the nozzle spout. Use an electronic multimeter set on the high range of the ohmmeter function. Resistance should not indicate more than 70,000 ohms per foot of hose. Example: The measured resistance for a 12-foot hose must not exceed 840,000 ohms (840 kilohms).

## 4 Procedure for Positioning the Liquid-Removal Device

---

This procedure must be followed to insure proper positioning for the liquid removal device in Part Number Series: VDV-EVR (See figure 2).

1. After installing the VST hanging hardware, hold the nozzle straight out from the dispenser so that the compressed bellows is 48 inches away from the front face of the dispenser and the spout tip of the nozzle is 30 inches above the pavement. The nozzle spout is to be at a 30 degree angle above the horizontal plane. (Simulate when the bellows is compressed in the filler neck of a vehicle.)

2. When the hose and nozzle are held in position as shown in Figure 2, the factory installed liquid removal device indicator mark on the vapor hose must be at the bottom of the loop.

If the indicator mark is not at the bottom of the primary hose loop, the installer may choose one of the following options:

- Adjust the hose retractor (if installed)
- Use a different length whip hose
- Use a different length primary hose

## 5 Maintenance

---

Inspect hoses daily for damage, loose connection, or leaks. Replace as necessary. Subject to customer abuse, hose should be replaced when damaged.

The hose is designed and constructed to give lasting service if properly handled and maintained. If for any reason it should need attention, contact your VST distributor for proper disposition.

### **NOTE:**

Due to abuse, misuse, changing gasoline formulas, variation in maintenance practices, environmental conditions, and/or conditions beyond the manufacture's control, dispensing equipment may need replacement before five (5) years. Inspections and proper maintenance procedures should be followed by the station manager to determine if replacement is required before five (5) years.

### **WARNING:**

Unauthorized rebuilding or modifying of hoses voids **ALL** approvals and warranties.

VST products must be used in compliance with applicable federal, state and local laws and regulations.





Figure 1: EVR Balance Hanging Hardware Assembly



**Figure 2: Procedure for Positioning the Liquid Removal Device**

**IMPORTANT:**

It is the installing technician's responsibility to insure that the properly-sized and marked hanging hardware is installed at the dispenser. Failure to properly install and locate the liquid-removal device may reduce the effectiveness of the product in application resulting in outer hose liquid blockage and failure of the liquid removal test procedure.